

MP2-10MTS Series

User Manual v1.0



Master Series Embedded System

Intel® Meteor Lake-U Core Ultra 7/5 Processors
Performance, Versatile, and Rugged & Reliable

PREFACE

Copyright Notice

Copyright © MiTAC Digital Technology Corporation (MiTAC Group). No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of MiTAC Corp., Ltd. All information and specification provided in this manual are for reference only and remain subject to change without prior notice.


Disclaimer

We reserve the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. We assume no responsibility or liability for the use of the described product(s) conveys no license or title under any patent, copyright, or masks work rights to these products, and make no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. We make no representation or guarantee that such application will be suitable for the specified use without further testing or modification.

Declaration of Conformity

	<p>FCC</p> <p>This equipment has been tested and found to comply with the limits for a class "A" digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at him own expense.</p>
	<p>CE</p> <p>This equipment is in conformity with the requirement of the following EU legislations and harmonized standards. Product also complies with the Council directions.</p>

Safety Information

	<p>WARNING! / AVERTISSEMENT!</p> <p>Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.</p>
	<p>CAUTION/ATTENTION</p> <p>Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.</p>

Safety Precautions

For your safety, please carefully read all the safety instructions before using the device. All cautions and warnings on the equipment should be noted. Keep this user manual for future reference.

***Let service personnel to check the equipment in case any of the following problems appear:**

- The power cord or plug is damaged.
- Liquid has penetrated into the equipment.
- The equipment has been exposed to moisture.
- The equipment does not work well or you cannot get it to work according to the user manual.
- The equipment has been dropped and damaged.
- The equipment has obvious signs of breakage on the surface.

部件名称 Part Name	有害物质 Hazardous Substances					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr ⁺⁶)	多溴联苯 (PBB)	多溴二苯 (PBDE)
印刷电路板 PCBA	X	O	O	O	O	O
金属部件 Metal Parts	X	O	O	O	O	O
电缆及电缆组 Cable and Cable Assemblies	X	O	O	O	O	O
其他外壳组件 Other Enclosure components	O	O	O	O	O	O
说明书 Manual	O	O	O	O	O	O

本表格依据SJ/T 11364的规定编制。

This table is prepared in accordance with the provisions of SJ/T 11364-2014.

O:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。

O: Indicates that the hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T26572.

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

X: Indicates that the hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T26572.



在中国大陆销售的相应电子信息产品(EIP)都必须遵照中国大陆《电子信息产品污染控制标识要求》标准贴上环保使用期限(EFUP)标签。MiTAC 产品所采用的 EFUP 标签【请参阅实例，徽标内部的编号使用于制定产品】基于中国大陆的《电子信息产品环保使用期限通则》标准。

All Electronic Information Products (EIP) that are sold within Chinese Mainland must comply with the “Electronic Information Products Pollution Control Labeling Standard” of Chinese Mainland, marked with the Environmental Friendly Use Period (EFUP) logo. The number inside the EFUP logo that MiTAC uses (please refer to the photo) is based on the “Standard of Electronic Information Products Environmental Friendly Use Period” of Chinese Mainland.


Ordering Information

Model Number	CPU Model	AC Adaptor
MP2-10MTS-125U	Core Ultra 5 125U	w/o AC Adaptor
MP2-10MTS-155U	Core Ultra 7 155U	
MP2-10MTS-125U-AC	Core Ultra 5 125U	w/ 72W AC to DC Adaptor
MP2-10MTS-155U-AC	Core Ultra 7 155U	

Packing List

Item	Description	Q'ty
1	MP2-10MTS Embedded System	1
2	Quick Installation Guide (1 page)	1
3	Wall Mount Brackets (2 pcs in 1 set)	2
4	Screw Pack (For HDD and Wall Mount Bracket)	1
5	3-pin Terminal Block Power Connector (For DC Power Input)	1
6	2-pin Terminal Block Power Connector (For Remote Power Control)	1

Optional Xpansion Modules and Accessories

Model Number	Description
<p>MS-01PON-S10-MP2</p> 	<p>802.3at PoE+ (Power budget 50W) Expansion Module for on board 4 x 2.5G LAN</p>
<p>MB-01DINVESA-MPB2</p> 	<p>Din-rail mount and VESA 75x75 holes transfer bracket + transfer plate kit (for MP2 and MB2 models only)</p>
<p>M2-02LAN-R10MP2</p> 	<p>Expansion Module with 2 x Intel i210-IT Giga LAN Port</p>
<p>M2-BM-KEY-HS-MP2</p> 	<p>Thermal kit for M.2 M key 2280 slot</p>
<p>MPE-072W24-3TUE</p>	<p>AC/DC 24V/3A, 72W 3PIN Terminal Block Power Adaptor with EU+US power cords</p>
<p>MPE-120W24-3TUE</p>	<p>AC/DC 24V/5A, 120W 3PIN Terminal Block Power Adaptor with EU+US power cords</p>

CONTENTS

PREFACE 1

CHAPTER 1: INTRODUCTION	10
1.1 Overview	10
1.2 Product Features	10
1.3 Hardware Specification	11
1.4 Mechanical Specification	14
1.5 System I/O Placement	15
CHAPTER 2: DIP SWITCH SETTING AND PIN DEFINITION	17
2.1 Jumper and Internal Connector Overall Placement.....	17
2.2 Jumper Setting	18
2.3 Connector Pin Definition.....	20
CHAPTER 3: SYSTEM SETUP.....	23
CHAPTER 4: BIOS SETUP.....	25
4.1 Main Page.....	25
4.2 Advanced Page	27
4.3 Trusted Computing SMART Settings	33
4.4 Super IO Configuration.....	34
4.5 Hardware Monitor	40
4.6 S5 RTC Wake Settings	42
4.7 Network Stack Configuration	43
4.8 NVMe Configuration	44
4.9 Intel ^(R) Rapid Storage Technology	45
4.10 Security Page	46
4.11 Boot Page	53
4.12 Save & Exit Page	57
4.13 MEBx	58

INTRODUCTION

This chapter provides the MP2-10MTS Embedded System product overview, including features, hardware and mechanical specifications.

1

CHAPTER 1: INTRODUCTION

This chapter provides the MP2-10MTS Embedded System product overview, including features, hardware, mechanical specifications, and I/O placement.

1.1 Overview

MiTAC's MP2-10MTS embedded system represents the next generation of embedded technology, featuring the Intel® Meteor Lake-U Core Ultra 7/5 processors. These processors integrate an NPU and Iris Xe graphics engine, delivering exceptional AI inference performance. With outstanding graphics capabilities, robust processing power, OCP/OVP power protection, and an expandable design, this system offers versatile solutions for complex tasks and a wide range of applications.

1.2 Product Features

MP2-10MTS Embedded System offers the following features:

- Intel® Meteor Lake U Core™ Ultra 7 155U / Ultra 5 125U processors
- Outstanding graphic computing capability with Integrated 4 x Intel® Iris Xe graphics
- 1 x DDR5 SO-DIMM and support up to 48GB
- Supports Triple display for HDMI, DisplayPort, and Type-C (DP Alt Mode)
- 1 x 2.5" SSD/HDD slot
- 4 x Intel® i226-LM 2.5G LAN (Option: additional PoE+ support via MS-01PON-S10-MP2 or additional 2 x i210-IT LAN expansion via M2-02LAN-R10-MP2)
- 3 x USB 2.0, 4 x USB 3.2 Gen2, 1 x USB Type C, and 4 x COM
- 8V~26V wide voltage power input
- -40 ~ 60°C wide temperature

*with 0.7m/s Air Flow (w/ Extended Temp. SSD/mSATA/RAM)

1.3 Hardware Specification

SYSTEM	
CPU	Intel® Meteor Lake-U Core™ Ultra 7 155U / Ultra 5 125U Processor
System Memory	DDR5 4800 MHz / 1 x 262-pin SO-DIMM / Max. 48GB (Non-ECC)
Graphics	Intel® Iris Xe Graphics
Display Interface	DisplayPort 1.2 / HDMI 1.4
Storage Slot	1 x 2.5" HDD/SSD bracket 1 x M.2 B Key 2242 SATA SSD Slot 1 x M.2 M Key 2280 NVMe/SATA SSD Slot
Ethernet	4 x Intel® I226-LM 2.5G LAN (Optional PoE Module) Additional 2 x Intel® I210-IT Giga LAN for Options
Audio	Realtek® ALC888S
I/O Chipset	Nuvoton NCT6126D
TPM	Nuvoton NPCT760AABYX TPM2.0
Expansion Slot	1 x M.2 2242/3042/3052 B Key (USB2.0/PCIeX1/SATAIII) 1x M.2 2280 M key (PCIe4.0 X4, SATAIII) 1 x M.2 2230 E key (PCIeX1, USB2.0)
Indicator	Power LED, HDD LED
FRONT I/O	3 x RS232 1 x RS232 / 422 / 485 8-bit GPIO in DB9 type 2 x USB 2.0 1 x Line-out HDD LED & Power LED Power Button 4 x SMA hole with rubber cap for wireless expansion
REAR I/O	4 x RJ-45 1 x USB Type C (Support PD15W, 5V/3A, DP Alt mode, USB3.2 Gen1) 4 x USB 3.2 Gen 2 (10 Gbps) 1 x USB 2.0 (integrated in the same blue type connector) 1 x HDMI 1.4 1 x DisplayPort 1.2 1 x 3-pin Terminal Block Power Input 1 x 2-pin Terminal Block Remote Power on / off 1 x Nano SIM slot with cover 2 x SMA hole with rubber cap for wireless expansion
Watchdog Timer	1~255 Steps by Software Program

POWER REQUIREMENT	
Power Input	8~26V Wide Range DC Input w/ Terminal Block Connectivity
MECHANICAL	
Thermal Design	Fanless
Mounting	Wall Mount / Side Mount 75 mm x 75 mm VESA Holes & Din Rail Mount Combo Kit (Optional)
Dimension	8.3" x 5.9" x 2.5" (210 x 150 x 63 mm)
Material	Top cover: Aluminum Alloy , Bezel and chassis: Steel
ENVIRONMENTAL	
Operating Temperature	-40 ~ 60°C *with 0.7m/s Air Flow (w/ Extended Temp. SSD/mSATA/RAM)
Operating Humidity	10%~95% R/H (Non-condensing)
Vibration Resistance	Operating, 2 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
Shock Resistance	Operating, 50 Grms, Half-sine 11 ms Duration (w/ SSD, according to IEC60068-2-27)
Certification	EMC: CE & FCC Safety: compliant with LVD, EN62368-1
OS	
OS Support	Windows® 11 64-bit, Windows® 10 64-bit, Linux (support by request)




**Notes¹: Installation in Restricted Access Location (RAL)*

A restricted access location is a designated area within an incident area (High or Low temperature environment)

With authorized people can enter for a period of time and for a specific purpose.

- 1. Access can only be gained by service people or by users who have been instructed about the reasons for the Restrictions applied to the location and about any precautions that shall be taken.*
- 2. Access is through the use of a tool or lock and key, or other means of security, and is controlled by the authority Responsible for the location.*



**Notes²: Please make sure that the power consumption is in the spec of the power supply output capability from AC adaptor (72W or 120W). Please choose the suitable AC adaptor for your application.*

AC/DC 24V/3A, 72W 3PIN Terminal Block Power Adaptor

AC/DC 24V/5A, 120W 3PIN Terminal Block Power Adaptor






**Note³: The safety ambient operating temperature is 40 degree C if the external AC adapter model: EA10681V or EA11011M will be placed in the same high temperature area with the embedded system.*




**Note⁴: CAUTION - Lithium battery is included in this embedded system. Please do not puncture, mutilate, or dispose of battery in fire. There will be danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by manufacturer. Dispose of used battery according to manufacturer instructions and in accordance with your local regulations.*

1.4 Mechanical Specification



- Mechanical Dimension: 210 mm x 150 mm x 63 mm



WALL MOUNT MODE




SIDE MOUNT MODE




1.5 System I/O Placement

MP2-10MTS

■ Front I/O:



■ Rear I/O:



DIP SWITCH SETTING AND PIN DEFINITION

This chapter provides information about how to set up the dip switch and use internal I/Os of MP2-10MTS Embedded System hardware.


2

CHAPTER 2: DIP SWITCH SETTING AND PIN DEFINITION

This chapter provides information about how to set up the dip switch, and use internal I/Os of MP2-10MTS Embedded System hardware.

2.1 Jumper and Internal Connector Overall Placement

Top View



Bottom View




Item	Description
A	Front IO audio connector
B	Headphone type select header
C	CMOS header
D	RTC battery connector
E	USB 2.0 header
F	Fan connector
G	Front IO header
H	RS-232 header. (COM3+COM4)
I	RS-232 /422/485(COM1)+RS-232(COM2)connector
J	MiAPI connector
K	ATX mode header
L	Panel power header
M	Backlight connector
N	Backlight voltage select header
O	SATA connector
P	SATA power header
Q	POE power board connector
R	Speaker connector
S	DC-in header

2.2 Jumper Setting

CMOS Header (C)

CMOS Clear Header




Vendor: [Joint Tech](#)
 Model: [A2015WV-03PN6BG1NY3L](#)

CMOS Clear

1-2	Clear CMOS
2-3	Secured RTC Reset

ATX Mode Header (K)

AT/ATX Header



Vendor: **Joint Tech**

Model: **A2015WV-03PN6BG1NY3L**

AT/ATX mode

1-2	AT Mode
2-3	NON-AT

Headphone type select header (B)




Vendor: **SUPERIOR TECH**

Model: **PHED-SS004G1ABONE-B331**

Pin	Signal Name	Description
1	MIC_R_JACK	Jumper default (1-2)
2	MIC2	Jumper default (1-2)
3	GND	Jumper default (3-4)
4	MIC_L_JACK	Jumper default (3-4)


2.3 Connector Pin Definition

■ 8-bit GPIO



DB9	GPIO	DB9	GPIO
1	GP1	2	GP5
3	GP2	4	GP6
5	GP3	6	GP7
7	GP4	8	GP8
9	GND		

■ COM#1(RS232/422/485) / COM#2~COM#4 (RS232)




Pin No	RS-232	RS-422	RS-485
1	DCD	TX-	DATA-
2	RX	TX+	DATA+
3	RTX	RX+	NC
4	DTR	RX-	NC
5	GND	GND	GND
6	DSR	NC	NC
7	RTS	NC	NC
8	CTS	NC	NC
9	RI	NC	NC

■ 3-pin terminal block for DC Input



Pin	Signal
1	DC IN +8~26VIN
2	-
3	GND

■ 2-pin terminal block for remote power on/off



Vendor: 祥益精密 (XIAN YI)
 Model: HE-ECH350R-02PLWR

Pin	Signal Name	Description	Pin	Signal Name	Description
1	TB_PWRBT_N	Power button#	2	Ground	Ground

SYSTEM SETUP

This chapter provides information about how to set up the MP2-10MTS Embedded System hardware installation.

3

CHAPTER 3: SYSTEM SETUP








This chapter provides information about how to set up the MP2-10MTS Embedded System hardware installation.



Warning: The edge of MP2-10MTS aluminum extrusion fins is a little bit sharp. Please be careful when you move the unit, do the installation, and operate the embedded system!

MP2-10MTS

Quick Assembly Guide

<p>Open Bottom Cover</p>  <p>1. Loosen 6 screws from Bottom cover as the dash line locations.</p>	<p>Release HDD Tray</p>  <p>2. Loosen 4 screws of HDD tray as arrow direction & pull out HDD tray.</p>	<p>Release M.2 Heatsink</p>  <p>3. Loosen 4 screws of M.2 heatsink as the dash line locations & pull out heatsink.</p>
<p>DRAM Maintenance</p>  <p>4. Install DIMM to MB on dash line area , no need to disassemble HDD tray and M.2 heatsink.</p>	<p>M.2 B-Key 4G/5G Card Installation</p>  <p>5. Install 4G/5G card on M.2 slot & plug in antenna IPEX header on 4G/5G card as arrow locations, then install the SIM card from rear IO.</p>	<p>M.2 M-Key SSD Installation</p>  <p>6. Install M.2 SSD on M.2 slot on dash line area.</p>
<p>M.2 E-Key Wi-Fi Card Installation</p>  <p>7. Disassemble M.2 SSD, install Wi-Fi card on M.2 slot & plug in antenna IPEX header on Wi-Fi card as arrow locations, then assemble the M.2 SSD back.</p>	<p>HDD Installation on Tray</p>  <p>8. Install HDD into HDD tray, pick up HDD screw kit from accessory and fixed as dash line locations.</p>	<p>POE Module Installation</p>  <p>9. Install POE bracket to chassis, hex stud on MB and fixed as dash line locations then install POE module on MB and fixed as dash line locations.</p>

BIOS SETUP


This chapter provides information about how to set up BIOS and use BIOS menu items to adjust basic function settings.

4

CHAPTER 4: BIOS SETUP

This chapter provides information about how to set up BIOS and use BIOS menu items to adjust basic function settings.

4.1 Main Page



Field Name	BIOS Vendor
Default Value	American Megatrends
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Core Version
Default Value	5.32
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Compliancy
Default Value	UEFI 2.9 ; PI 1.7
Comment	This field is not selectable. There is no help text associated with it.

Field Name	BIOS Version
------------	---------------------

Default Value	Display the version of the BIOS
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Build Date
Default Value	Display build date of the BIOS
Comment	This field is not selectable. There is no help text associated with it.

Field Name	ME FW Version
Value	ME Firmware Version.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Processor Information
Value	Display the installed CPU brand.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Microcode Revision
Value	Display the CPU microcode revision.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Total Memory
Value	Display the installed memory size.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Memory Frequency
Value	Display the installed memory frequency.
Comment	This field is not selectable. There is no help text associated with it.


Field Name	Serial ATA Port 0
Value	Display the installed SATA device model/size.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Serial ATA Port 1
Value	Display the installed SATA device model/size.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	System Date
Default Value	[Www mm/dd/yyyy]
Possible Value	Www : Mon/Tue/Wed/Thu/Fri/Sat/Sun mm : 1-12 dd : 1-31 yyyy : 1998-9999
Help	Set the Date. Use Tab to switch between Date elements. Default Ranges: Year : 1998-9999 Months : 1-12 Days : Dependent on month Range of Years may vary.

Field Name	System Time
Default Value	[hh :mm :ss]
Possible Value	hh : 0-23 mm : 0-59 ss : 0-59
Help	Set the Time. Use Tab to switch between Time elements.

4.2 Advanced Page



Field Name	Onboard Device
Help	Onboard Device Configuration.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	CPU Configuration
Help	CPU Configuration Parameters.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Trusted Computing
Help	Trusted Computing Settings
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	SMART Settings
Help	System SMART Settings
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Super IO Configuration
Help	System Super IO Chip Parameters.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Hardware Monitor
Help	Monitor hardware status
Comment	Press Enter when selected to go into the associated Sub-Menu.


Field Name	S5 RTC Wake Settings
Help	Enable system to wake from S5 using RTC alarm
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Network Stack Configuration
Help	Network Stack Settings.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	NVMe Configuration
Help	NVMe Device Options Settings
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Intel(R) Rapid Storage Technology
Help	This Formset allows the user to manage RAID volumes on the Intel(R) RAID Controller
Comment	Press Enter when selected to go into the associated Sub-Menu.

4.2.1 Onboard Device



Field Name	LVDS/eDP Panel
Default Value	[Disabled]
Possible Value	Enabled Disabled
Help	LVDS/eDP Panel Enable/Disable

Field Name	Turbo Mode
Default Value	[Enabled]
Possible Value	Enabled Disabled
Help	Enable/Disable processor Turbo Mode.

Field Name	State After G3
Default Value	[S5 State]
Possible Value	S0 State S5 State
Help	Specify what state to go to when power is re-applied after a power failure (G3 state).

Field Name	Wake on LAN Enable
Default Value	[Enabled]
Possible Value	Enabled Disabled
Help	Enable/Disable LAN to wake the system.


Field Name	HD Audio
Default Value	[Enabled]
Possible Value	Enabled Disabled
Help	Control Detection of the HD-Audio device. Disabled = HDA will be unconditionally disabled Enabled = HDA will be unconditionally enabled.

Field Name	NPU Device (B0:D11:F0)
Default Value	[Enabled]
Possible Value	Enabled Disabled
Help	Enable/Disable NPU (Neural Processing Unit) Device.

Field Name	Enable VMD controller
Default Value	[Disabled]
Possible Value	Enabled Disabled
Help	Enable/Disable to VMD controller

4.2.2 CPU Configuration






Field Name	ID
Default Value	Displays CPU Signature
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Brand String
Default Value	Displays the CPU brand string
Comment	This field is not selectable. There is no help text associated with it.

Field Name	VMX
Default Value	VMX Supported or Not
Comment	This field is not selectable. There is no help text associated with it.

4.2.3 Trusted Computing




Field Name	Firmware Version
Default Value	TPM module version.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Vendor
Default Value	TPM module vendor name.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Security Device Support
Default Value	[Enable]
Possible Value	Enable Disable
Help	Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.


Field Name	Pending operation
Default Value	[None]
Possible Value	None TPM Clear
Help	Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change State of Security Device.

4.3 Trusted Computing SMART Settings



Field Name	SMART Self Test
Default Value	[Disabled]
Possible Value	Enabled Disabled
Help	Run SMART Self Test on all HDDs during POST.

4.4 Super IO Configuration




Field Name	Serial Port 1 Configuration
Help	Set Parameters of Serial Port 1 (COMA)
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Serial Port 2 Configuration
Help	Set Parameters of Serial Port 2 (COMB)
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Serial Port 3 Configuration
Help	Set Parameters of Serial Port 3 (COMC)
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Serial Port 4 Configuration
Help	Set Parameters of Serial Port 4 (COMD)
Comment	Press Enter when selected to go into the associated Sub-Menu.

4.4.1 Serial Port 1 Configuration



Field Name	Serial Port
Default Value	[Enabled]
Possible Value	Disabled Enabled
Help	Enable or Disable Serial Port(COM)

Field Name	Device Settings
Default Value	Device Super IO COM1 Address and IRQ.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Change Settings
Default Value	[Auto]
Possible Value	Auto; IO=3E8h;IRQ=7; IO=3E8h;IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h;IRQ=3,4,5,6,7,9,10,11,12; IO=220h;IRQ=3,4,5,6,7,9,10,11,12; IO=228h;IRQ=3,4,5,6,7,9,10,11,12;
Help	Select an optimal settings for Super IO Device

Field Name	Mode Configuration
Default Value	[3T/5R RS232]
Possible Value	1T/1R RS422

	3T/5R RS232 1T/1R RS485 TX ENABLE Low Active 1T/1R RS422 with termination resistor 1T/1R RS485 with termination resistor TX ENABLE Low Active Disabled
Help	Configure serial port as RS232/RS422/RS485.

4.4.2 Serial Port 2 Configuration




Field Name	Serial Port
Default Value	[Enabled]
Possible Value	Disabled Enabled
Help	Enable or Disable Serial Port(COM)

Field Name	Device Settings
Default Value	Device Super IO COM2 Address and IRQ.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Change Settings
Default Value	[Auto]
Possible Value	Auto; IO=2E8h;IRQ=7; IO=3E8h;IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h;IRQ=3,4,5,6,7,9,10,11,12; IO=220h;IRQ=3,4,5,6,7,9,10,11,12; IO=228h;IRQ=3,4,5,6,7,9,10,11,12;;
Help	Select an optimal settings for Super IO Device

4.4.3 Serial Port 3 Configuration




Field Name	Serial Port
Default Value	[Enabled]
Possible Value	Disabled Enabled
Help	Enable or Disable Serial Port(COM)

Field Name	Device Settings
Default Value	Device Super IO COM3 Address and IRQ.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Change Settings
Default Value	[Auto]
Possible Value	Auto; IO=3E8h;IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h;IRQ=3,4,5,6,7,9,10,11,12; IO=220h;IRQ=3,4,5,6,7,9,10,11,12; IO=228h;IRQ=3,4,5,6,7,9,10,11,12;
Help	Select an optimal settings for Super IO Device

4.4.4 Serial Port 4 Configuration




Field Name	Serial Port
Default Value	[Enabled]
Possible Value	Disabled Enabled
Help	Enable or Disable Serial Port(COM)

Field Name	Device Settings
Default Value	Device Super IO COM4 Address and IRQ.
Comment	This field is not selectable. There is no help text associated with it.

Field Name	Change Settings
Default Value	[Auto]
Possible Value	Auto; IO=3F8h;IRQ=4; IO=3F8h;IRQ=3,4,5,6,7,9,10,11,12; IO=2F8h;IRQ=3,4,5,6,7,9,10,11,12; IO=3E8h;IRQ=3,4,5,6,7,9,10,11,12; IO=2E8h;IRQ=3,4,5,6,7,9,10,11,12;
Help	Select an optimal settings for Super IO Device

4.5 Hardware Monitor



Field Name	CPU Temperature
Default Value	Display CPU Temperature
Comment	This field is not selectable. There is no help text associated with it.

Field Name	CPU VR Temperature
Default Value	Display CPU VR Temperature
Comment	This field is not selectable. There is no help text associated with it.

Field Name	DIMM Temperature
Default Value	Display DIMM Temperature
Comment	This field is not selectable. There is no help text associated with it.

Field Name	CPU Fan Speed
Default Value	Display CPU Fan Speed
Comment	This field is not selectable. There is no help text associated with it.

Field Name	CPU_CORE_MON (CPUVCORE)
Default Value	Display CPUVCORE Voltage
Comment	This field is not selectable. There is no help text associated with it.

Field Name	VCCSA_MON (ATX5VSB/VIN0)
Default Value	Display ATX5VSB/VIN0 Voltage
Comment	This field is not selectable. There is no help text associated with it.

Field Name	VDD2_MON (AUXTIN/VIN2)
Default Value	Display AUXTIN/VIN2 Voltage
Comment	This field is not selectable. There is no help text associated with it.

Field Name	VCCPRIM_IO (VTT)
Default Value	Display VCCPRIM_IO (VTT) Voltage
Comment	This field is not selectable. There is no help text associated with it.


Field Name	VCC3V
Default Value	Display VCC3V Voltage
Comment	This field is not selectable. There is no help text associated with it.

Field Name	VS3V
Default Value	Display VS3V Voltage
Comment	This field is not selectable. There is no help text associated with it.

Field Name	VBAT
Default Value	Display VBAT Voltage
Comment	This field is not selectable. There is no help text associated with it.

Field Name	AVSB
Default Value	Display AVSB Voltage
Comment	This field is not selectable. There is no help text associated with it.

4.6 S5 RTC Wake Settings



Field Name	Wake system from S5
Default Value	[Disabled]
Possible Value	Disabled Fixed Time
Help	Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr::min::sec specified.

Field Name	Wake up hour(Show when Wake system from S5 set to Fixed Time)
Default Value	0
Possible Value	0-23
Help	select 0-23 For example enter 3 for 3am and 15 for 3pm

Field Name	Wake up minute(Show when Wake system from S5 set to Fixed Time)
Default Value	0
Possible Value	0-59
Help	select 0 – 59 for Minute

Field Name	Wake up second(Show when Wake system from S5 set to Fixed Time)
Default Value	0
Possible Value	0 - 59
Help	select 0 – 59 for Second

4.7 Network Stack Configuration



Field Name	Network Stack
Default Value	[Disabled]
Possible Value	Disabled Enabled
Help	Enable/Disable UEFI Network Stack.

Field Name	IPv4 PXE Support (Available when Network Stack Enabled)
Default Value	[Disabled]
Possible Value	Disabled Enabled
Help	Enable/Disable IPv4 PXE boot support. If disabled, IPv4 PXE boot support will not be available.


Field Name	IPv6 PXE Support (Available when Network Stack Enabled)
Default Value	[Disabled]
Possible Value	Disabled Enabled
Help	Enable/Disable IPv6 PXE boot support. If disabled, IPv6 PXE boot support will not be available.

4.8 NVMe Configuration




Field Name	(Device)
Comment	Press Enter when selected to go into the associated Sub-Menu.

4.9 Intel^(R) Rapid Storage Technology



Field Name	(Device)
Comment	Press Enter when selected to go into the associated Sub-Menu.

4.10 Security Page



Field Name	Administrator Password
Help	Set Administrator Password

Field Name	User Password
Help	Set User Password.

Field Name	HDD Security drive
Help	HDD Security Configuration for selected drive
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Secure Boot
Help	Secure Boot configuration
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	BIOS Update
Help	BIOS Update support
Comment	Press Enter when selected to go into the associated Sub-Menu.

4.10.1 HDD Security

Aptio Setup - AMI

Security

HDD Password Description :

Allows Access to Set, Modify and Clear
HardDisk User Password
User Password is mandatory to Enable HDD Security.
If the 'Set User Password' option is hidden,
do power cycle to enable the option again.

HDD PASSWORD CONFIGURATION:

Security Supported :	Yes
Security Enabled :	No
Security Locked :	No
Security Frozen :	Yes
HDD User Pwd Status:	NOT INSTALLED

←+: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Reset
ESC: Exit

Version 2.22.1292 Copyright (C) 2024 AMI

4.10.2 Secure Boot



Field Name	Secure Boot
Default Value	[Enabled]
Possible Value	Enabled Disabled
Help	Secure Boot feature is Active if Secure Boot is Enabled,Platform Key(PK) is enrolled and the System is in User mode.The mode change requires platform reset

Field Name	Secure Boot Mode
Default Value	[Standard]
Possible Value	Standard Custom
Help	Secure Boot mode options:Standard or Custom.In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication

Field Name	Restore Factory Keys
Help	Force System to User Mode. Install factory default Secure Boot key databases

Field Name	Reset To Setup Mode
Help	Delete all Secure Boot key databases from NVRAM

Field Name	Key Management
Help	Enables expert users to modify Secure Boot Policy variables without variable authentication
Comment	Enables expert users to modify Secure Boot Policy variables without variable authentication

Help	Enroll Factory Defaults or load certificates from a file: 1.Public Key Certificate: a)EFI_SIGNATURE_LIST b)EFI_CERT_X509 (DER) c)EFI_CERT_RSA2048 (bin) d)EFI_CERT_SHAXXX 2.Authenticated UEFI Variable 3.EFI PE/COFF Image(SHA256) Key Source: Factory,Modified,Mixed
comment	Press Enter when selected to go into the associated Sub-Menu “Key Management”.

Field Name	Key Exchange Keys (KEK)
Default Value	Size:0, Keys:0, Key Source: No Keys
Help	Enroll Factory Defaults or load certificates from a file: 1.Public Key Certificate: a)EFI_SIGNATURE_LIST b)EFI_CERT_X509 (DER) c)EFI_CERT_RSA2048 (bin) d)EFI_CERT_SHAXXX 2.Authenticated UEFI Variable 3.EFI PE/COFF Image(SHA256) Key Source: Factory,Modified,Mixed
comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Authorized Signatures (db)
Default Value	Size:0, Keys:0, Key Source: No Keys
Help	Enroll Factory Defaults or load certificates from a file: 1.Public Key Certificate: a)EFI_SIGNATURE_LIST b)EFI_CERT_X509 (DER) c)EFI_CERT_RSA2048 (bin) d)EFI_CERT_SHAXXX 2.Authenticated UEFI Variable 3.EFI PE/COFF Image(SHA256) Key Source: Factory,Modified,Mixed
comment	Press Enter when selected to go into the associated Sub-Menu.


Field Name	Forbidden Signatures (dbx)
Default Value	Size:0, Keys:0, Key Source: No Keys
Help	Enroll Factory Defaults or load certificates from a file: 1.Public Key Certificate: a)EFI_SIGNATURE_LIST b)EFI_CERT_X509 (DER) c)EFI_CERT_RSA2048 (bin) d)EFI_CERT_SHAXXX 2.Authenticated UEFI Variable 3.EFI PE/COFF Image(SHA256) Key Source: Factory,Modified,Mixed
comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	Authorized TimeStamps (dbt)
Default Value	Size:0, Keys:0, Key Source: No Keys
Help	Enroll Factory Defaults or load certificates from a file:

	1.Public Key Certificate: a)EFI_SIGNATURE_LIST b)EFI_CERT_X509 (DER) c)EFI_CERT_RSA2048 (bin) d)EFI_CERT_SHAXXX 2.Authenticated UEFI Variable 3.EFI PE/COFF Image(SHA256) Key Source: Factory,Modified,Mixed
comment	Press Enter when selected to go into the associated Sub-Menu.


Field Name	OsRecovery Signatures (dbr)
Default Value	Size:0, Keys:0, Key Source: No Keys
Help	Enroll Factory Defaults or load certificates from a file: 1.Public Key Certificate: a)EFI_SIGNATURE_LIST b)EFI_CERT_X509 (DER) c)EFI_CERT_RSA2048 (bin) d)EFI_CERT_SHAXXX 2.Authenticated UEFI Variable 3.EFI PE/COFF Image(SHA256) Key Source: Factory,Modified,Mixed
comment	Press Enter when selected to go into the associated Sub-Menu.

4.10.4 BIOS Update



Field Name	Path for ROM Image
Help	Enter the path to the BIOS update option

4.11 Boot Page



Field Name	Setup Prompt Timeout
Default Value	1
Possible Value	1~65535
Help	Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.

Field Name	Bootup NumLock State
Default Value	[On]
Possible Value	On Off
Help	Select the keyboard NumLock state

Field Name	Boot Option #1
Default Value	[USB Floppy]
Possible Value	USB Floppy, CD/DVD, USB CD/DVD, Hard Disk , USB Key, USB Hard Disk , Network, Disabled
Help	Sets the system boot order

Field Name	Boot Option #2
Default Value	[CD/DVD]
Possible Value	USB Floppy, CD/DVD, USB CD/DVD, Hard Disk , USB Key, USB Hard Disk , Network, Disabled

Help	Sets the system boot order
------	----------------------------

Field Name	Boot Option #3
Default Value	[USB CD/DVD]
Possible Value	USB Floppy, CD/DVD, USB CD/DVD, Hard Disk , USB Key, USB Hard Disk , Network, Disabled
Help	Sets the system boot order

Field Name	Boot Option #4
Default Value	[Hard Disk]
Possible Value	USB Floppy, CD/DVD, USB CD/DVD, Hard Disk , USB Key, USB Hard Disk , Network, Disabled
Help	Sets the system boot order

Field Name	Boot Option #5
Default Value	[USB Key]
Possible Value	USB Floppy, CD/DVD, USB CD/DVD, Hard Disk , USB Key, USB Hard Disk , Network, Disabled
Help	Sets the system boot order

Field Name	Boot Option #6
Default Value	[USB Hard Disk]
Possible Value	USB Floppy, CD/DVD, USB CD/DVD, Hard Disk , USB Key, USB Hard Disk , Network, Disabled
Help	Sets the system boot order

Field Name	Boot Option #7
Default Value	[Network]
Possible Value	USB Floppy, CD/DVD, USB CD/DVD, Hard Disk , USB Key, USB Hard Disk , Network, Disabled
Help	Sets the system boot order

Field Name	(UEFI) USB Floppy Drive BBS Priorities
Help	Specifies the Boot Device Priority sequence from available UEFI USB Floppy Drives.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	(UEFI) CDROM/DVD Drive BBS Priorities
Help	Specifies the Boot Device Priority sequence from available UEFI CDROM/DVD Drives.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	(UEFI) USB CDROM/DVD ROM Drive BBS Priorities
Help	Specifies the Boot Device Priority sequence from available UEFI USB CDROM/DVD Drives.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	(UEFI) Hard Disk Drive BBS Priorities
Help	Specifies the Boot Device Priority sequence from available UEFI Hard Disk Drives.
Comment	Press Enter when selected to go into the associated Sub-Menu.


Field Name	(UEFI) USB Key Drive BBS Priorities
------------	--

Help	Specifies the Boot Device Priority sequence from available UEFI USB Key Drives.
Comment	Press Enter when selected to go into the associated Sub-Menu.

Field Name	(UEFI) USB Hard Disk Drive BBS Priorities
Help	Specifies the Boot Device Priority sequence from available UEFI USB Hard Disk Drives.
Comment	Press Enter when selected to go into the associated Sub-Menu.


Field Name	(UEFI) NETWORK Drive BBS Priorities
Help	Specifies the Boot Device Priority sequence from available UEFI NETWORK Drives.
Comment	Press Enter when selected to go into the associated Sub-Menu.

4.11.1 (List Boot Device Type) Drive BBS Priorities



Field Name	Boot Option #1
Default Value	
Possible Value	Boot Device Name 1 of this type, Disable
Help	Sets the system boot order

4.12 Save & Exit Page



Field Name	Save Changes and Reset
Help	Reset the system after saving the changes.

Field Name	Discard Changes and Reset
Help	Reset system setup without saving any changes.

Field Name	Restore Defaults
Help	Restore/Load Default values for all the setup options.

4.13 MEBx

Note: This page will not display if Intel AMT not support.



Field Name	Intel® ME Password
Default	admin (Force change new password after first entering.)
Help	MEBx Login

Password rule:

1. Password Length: At least 8 characters, and no more than 32.
2. Password Complexity: Password must include the following:
 - At least one digit character ('0', '1', ... '9')
 - At least one 7-bit ASCII non alpha-numeric character (e.g. '!', '\$', ';'), but excluding ':', ',' and "" characters.
 - At least one lower-case letter ('a', 'b'...'z') and at least one upper case letter ('A', 'B'...'Z').